



Rolled Rubber Sport Maintenance

Keep surface free from loose debris by sweeping, using a dust mop or by vacuuming the surface daily or as needed.

Damp mop surface by using a microfiber mop head or by using an auto scrubber fitted with a soft nylon brush.

Use Diversey Profi Floor Cleaner and Grease Remover as the detergent and dilute 6-10 oz/gallon water.

Use a wet vacuum to pick up the cleaning solution from the floor and rise with clean water. Do not flood the floor.

The rinse water should then be wet vacuumed from the floor. Allow the floor to dry before foot traffic.

Greatmats.com
117 Industrial Ave
Milltown, WI 54858
877-822-6622
info@greatmats.com